

## **WATER DAM INSTALLATION:**

*Tools needed are hack saw and measuring tape.*

1. Measure the opening.
2. Cut track 1/32" less than measurements.
3. Cut vinyl water dam to fit length of track.
4. Apply a high quality silicone bathroom caulk to the bottom of the track and press into position.